

PRODUCT INFORMATION

Full vision safety glasses



Application range and properties

- + **Features:** Special version (based on the requirements of Berner International) of the well-known UVEX Safety Goggle, full vision, non-fogging and can be worn over corrective glasses. The elastic strap ensures a firm and fit.
- + **Area of application:** Protection from mechanical risks, liquids and coarse dust.
- + **Protection capacity:** Does not provide protection from high-speed particles, laser beams, temperatures of over 55°C, arcing faults, molten metals.
- + **Replacement interval:** Immediately in the event of visible contamination!
- + **Before use:** Check for any damage! Do not use goggles if marking is absent or illegible.
- + **Disposal:** If used in connection with cytostatics: waste requiring supervision (waste code: 18 01 04 in accordance with 2000/532/EC); in the event of heavy contamination, waste requiring special supervision (waste code: 18 01 08* in accordance with 2000/532/EC); collect and dispose of waste separately!
- + ¹⁾: Personal Protective Equipment

Versions

Order No. (non-sterile)	121405
Order No. (sterile)	121406
Size	Universal
Colour	Grey transparent

Frame marking

W	Code letter manufacturer
166	Number of standard
Application range	3 (drips & spray) / 4 (particulate matter)
Mechanical strength	F (45 m/s)
CE	EC conformity
0196	Notified body

Lens marking

W	Code letter of manufacturer
1	Optical class
N	Resistance to fogging
DIN	Certification
CE	EC-conformity
0196	Notified body

Care instructions

- + Cleaning: Using clean water and household washing-up liquid (no lye, acids or solvents!). Avoid a strong mechanical action when cleaning (scratched surface = high proportion of stray light).
- + Disinfection: Item can be disinfected with any standard disinfectant.

CE-marking

CE marking in accordance with the EU PPE regulation (EU) 2016/425. Type examination carried out based on DIN EN 166. Manufacturer: UVEX Arbeitsschutz GmbH, Fürth, Germany.

Notified body „0196“

DIN CERTCO, Gartenstr. 133, D-73430 Aalen, Deutschland.

Quality management system

Our quality management system is in accordance with DIN EN ISO 9001:2015 by TÜV Product Service GmbH. The quality of our products is ensured by regular audits and factory inspections.

Storage and transport requirements

Cool (+10 to +40°C); Dry (humidity max. 65%)

No contact with pointed and/or sharp objects

Shelf life

6 years from date of manufacture

Manufacturer / Distributor

UVEX Arbeitsschutz GmbH, Würzburger Str. 181 – 189, 90766 Fürth, Germany

Berner International GmbH, Werner-von-Siemens-Str. 19, 25337 Elmshorn,

Tel: +49 4121 43560, info@berner-safety.de, www.berner-safety.de
