

PRODUCTINFORMATION

3M Fahrenheit™ SA Safety goggles



Application range and properties

- + **Maximum protection and wearing comfort:**
Tested and certified safety goggles manufactured by 3M. Soft, wide frame, aerodynamic shape for increased comfort and safety, ideal for wearing over a dust or half mask, UV protection.
- + **Application range:**
Protection against particles and liquids. Unventilated, gas-tight protective goggles.
- + **Protection capacity:**
Suitable for particles up to 45 m / s. Best resistance to chemicals.
- + **Before use:**
Check for any damage! Do not use goggles if marking is missing or illegible.

Versions

Itemcode	121730
Size	Universal
Colour	Cristal blue

Properties

- 180° Distortion-free acetate lens
- Mechanical strength up to 45 m / s (F)
- Special coating - Hardium + technology against scratching and fogging
- Without ventilation, gas-tight
- Comfortable, easily adjustable nylon elastic band (23 mm)
- Including microfiber bag for window cleaning and storage

Frame marking

3M	Code letter of manufacturer
166	EN standard
F	Mechanical strenghts
3, 4, 9	Resistance to liquids, dust particles, molten metal & solids
230.1	
CE	EC-conformity
0194	Notified body

Lens marking

3M	Code letter of manufacturer
1	Optical class
F	Impact resistance up to 45 m / s
9	Resistance to metal & hot solids
N	Resistance to fogging
EN 166	Certification standard
CE	EC conformity
0194	Notified body

Care instructions

Cleaning: Using clean water and household washing-up liquid (no lye, acids or solvents!) Avoid a strong mechanical action when cleaning (Scratched surface: high proportion of stray light)

Desinfection: Item can be disinfected with any standard disinfectant.

CE-marking

CE-marking in accordance to EU PPE regulation 89/686/EWG. Type-testing based on DIN EN 166.

Notified body „0194“

INSPEC International Ltd, 56 Leslie Hough Way, Salford, Greater Manchester, M6 6AJ, Grossbritannien

Qualität management system

Our **Quality management system** is **tested and certified** by TÜV Product Service GmbH (a certification body accredited by the German Accreditation Council) in accordance with DIN EN ISO 9001:2015. Regular **audits and production site inspections** guarantee the quality of our products.

Storage and transport conditions

- Storage temperature +10 bis + 50°C; dry; humidity max. 90 %; no contact with sharp / pointed objects

Shelf life

- 5 years from date of manufacture

Distributor

Berner International GmbH, Werner-von-Siemens-Str. 19, 25337 Elmshorn, Tel: +49 4121 43560, Fax: +49 4121 435620, info@berner-safety.de, www.berner-safety.de

Manufacturer

3M United Kingdom PLC 3M Centre, Cain Road Bracknell, Berkshire RG12 8HT Tel.: 0870 60 800 60, www.3M.eu/Safety